

X96DS



"??? ??? ????? X96DSX ?? ??? : X96DSX025X21H ??? :mm 96*96 ??? ????? : 260-80 Vac/dc ????? ????? ????? : 30mA-30A ?????????? : 0.1sec-5sec ????? ????? : IP41 ????? External Reset

???? ?????: ????? ????? ????? ????
????

[?? ????? ?? ????? ??? ?????](#)

???????? ??

???? ????? ??? ????? ????? ?????.